

Broil King®

Broil King

CROWN 410
8659-52
8659-53



Broil King

CROWN 410
8650-52
8650-53
CROWN 410 R
8650-53R



Broil King

CROWN 430
8659-62
8659-63



Broil King

CROWN 430
8650-62
8650-63
CROWN 430 R
8650-63R



Broil King

CROWN 480
8659-82
8659-83










Broil King


CROWN 480
8650-82
8650-83



HARDWARE INCLUDED / MATERIAL INCLUS / EQUIPOS INCLUIDO




Y-12865		(12)	Y-29304		(6)
Y-11793		(4)	32001-151		(4)
S21235		(2)	S21233		(2)
S21084		(8)	S21125		(2)
					
20005-000					(1)

TOOLS REQUIRED / OUTILS NECESSAIRES / HERRAMIENTAS NECESARIAS






1

(2)




2

(8) (1)





3





4

(8)





5



(2) 



6







7







8


(4)














11




12










15


(2) 








17


(2) 





19





PARTS LIST

KEY #		ITEM #	DESCRIPTION	8650-52	8650-53	8650-53R	8650-62	8650-63	8650-63R	8650-82	8650-83	8659-52	8659-53	8659-62	8659-63	8659-82	8659-83
1	52005-107	FIRBOX ASSEMBLY	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
2	56005-801	LID ASSEMBLY	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
7	Y-11544S	SCREW - BURNER	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4
8	S21242	BURNER CLIP	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4
18	52001-981	COOKING GRID	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4
20	52005-991	GRID - WARMING RACK	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
21	59805-012	CONTROL ASSEMBLY	1	•	•	•	•	•	•	•	•	1	•	•	•	•	•
	59805-013	CONTROL ASSEMBLY	•	1	1	•	•	•	•	•	•	•	1	•	•	•	•
	59805-032	CONTROL ASSEMBLY	•	•	•	1	•	•	•	•	•	•	•	1	•	•	•
	59805-033	CONTROL ASSEMBLY	•	•	•	•	•	1	•	•	•	•	•	•	1	•	•
	59805-072	CONTROL ASSEMBLY	•	•	•	•	•	•	•	1	•	•	•	•	•	1	•
	59805-073	CONTROL ASSEMBLY	•	•	•	•	•	•	•	•	1	•	•	•	•	•	1
22	22025-903A	COLLECTOR BOX	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
24	10111-16A	CONNECTOR HOSE	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
25	18631	BURNER	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4
26	52002-298A	CONTROL KNOB	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4
27	52001-298A	CONTROL KNOB	•	•	•	1	1	1	1	2	2	•	•	1	1	2	•
28	52025-121CRO	CONTROL COVER	•	•	•	•	•	•	•	•	•	1	•	•	•	•	•
	52025-241CRO	CONTROL COVER	•	•	•	•	•	•	•	•	•	•	•	1	1	•	•
	52025-301CRO	CONTROL COVER	•	•	•	•	•	•	•	•	•	•	•	•	•	1	1
	52025-124CRO	CONTROL COVER	1	1	1	•	•	•	•	•	•	•	•	•	•	•	•
	52025-244CRO	CONTROL COVER	•	•	•	1	1	1	1	•	•	•	•	•	•	•	•
	52025-304CRO	CONTROL COVER	•	•	•	•	•	•	•	1	1	•	•	•	•	•	•
31	52009-918	EDGE CAP - LH	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
32	52009-938	EDGE CAP - RH	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
34A	Y-11230	COTTER PIN	•	•	•	1	1	1	1	1	1	•	•	1	1	1	1
37	53139-908	SHELF BRACKET SUPPORT	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4
38	Y-12620	SHELF LOCK CLIP	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4
41	10342-E13	ELECTRODE	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
42	10342-E22	ELECTRODE	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
44	53005-001A	ELECTRONIC IGNITOR	1	1	1	•	•	•	•	•	•	1	1	•	•	•	•
	53005-003A	ELECTRONIC IGNITOR	•	•	•	1	1	1	1	•	•	•	•	1	1	•	•
	53005-007A	ELECTRONIC IGNITOR	•	•	•	•	•	•	•	1	1	•	•	•	•	1	1
44A	25070-925	WIRE - IGNITOR	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
44B	25070-931	BUTTON - IGNITOR	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
48	52004-007	DRIP PAN	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
49	51009-007	GREASE PAN	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
50	52060-101	GREASE RAIL	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1

PARTS LIST

KEY #	ITEM #	DESCRIPTION	8650-52	8650-53	8650-53R	8650-62	8650-63	8650-63R	8650-82	8650-83	8659-52	8659-53	8659-62	8659-63	8659-82	8659-83
51	18431	FLAV-R-WAVE ®	4	4	4	4	4	4	4	4	4	4	4	4	4	4
52	52149-004	GREASE SHIELD	3	3	3	3	3	3	3	3	3	3	3	3	3	3
56	24005-12A	HANDLE	1	1	1	1	1	1	1	1	1	1	1	1	1	1
58	24009-936	BEZEL	2	2	2	2	2	2	2	2	2	2	2	2	2	2
59	10081-BK630	NAMEPLATE	1	1	1	1	1	1	1	1	1	1	1	1	1	1
60	18013	HEAT INDICATOR	1	1	1	1	1	1	1	1	1	1	1	1	1	1
62	53409-148	SHELF END CAP	2	2	2	2	2	2	2	2	2	2	2	2	2	2
65	20005-000	MATCH LIGHT - STICK	1	1	1	1	1	1	1	1	1	1	1	1	1	1
69	51585-106	FRONT PANEL	1	1	1	1	1	1	1	1	1	1	1	1	1	1
80	51189-101	SIDE PANEL	2	2	2	2	2	2	2	2	2	2	2	2	2	2
87	Y-11793	NUT 1/4-20	4	4	4	4	4	4	4	4	4	4	4	4	4	4
90	51625-131	BASE	1	1	1	1	1	1	1	1	1	1	1	1	1	1
99	32001-151	CASTOR BRACKET CAP	4	4	4	4	4	4	4	4	4	4	4	4	4	4
100	51639-108	CASTOR BRACKET	2	2	2	2	2	2	2	2	1	1	1	1	1	1
102	10892-286	CASTOR	4	4	4	4	4	4	4	4	4	4	4	4	4	4
103	21039-301	TANK BRACKET	1	1	1	1	1	1	1	1	1	1	1	1	1	1
113	10342-T14	SIDE BURNER ELECTRODE	•	•	•	1	1	1	1	1	•	•	1	1	1	1
114	53109-111	SHELF - RIGHT	1	1	1	1	1	1	1	1	1	1	1	1	1	1
115	53109-111	SHELF - LEFT	1	1	1	•	•	•	•	•	1	1	•	•	•	•
	53109-151	SHELF - SB - LEFT	•	•	•	1	1	1	1	1	•	•	1	1	1	1
123	Y-12117	BUSHING	•	•	•	2	2	2	2	2	•	•	2	2	2	2
124	53004-271	SIDE BURNER BODY	•	•	•	1	1	1	1	1	•	•	1	1	1	1
125	53000-251	SIDE BURNER COVER	•	•	•	1	1	1	1	1	•	•	1	1	1	1
126	10390-E10D	SIDE BURNER	•	•	•	1	•	•	1	•	•	•	1	•	1	•
	10390-E10E	SIDE BURNER	•	•	•	•	1	1	•	1	•	•	•	1	•	1
128	53009-951	GRID	•	•	•	1	1	1	1	1	•	•	1	1	1	1
129	Y-11990	HEX NUT	•	•	•	•	•	•	1	1	•	•	•	•	1	1
130	27905-354	BURNER ROTISSERIE	•	•	•	•	•	•	1	1	•	•	•	•	1	1
133	S15278	ROTISSERIE HARDWARE	•	•	1	•	•	1	1	1	•	•	•	•	1	1
137	S15256	SPIT ROD	•	•	1	•	•	1	1	1	•	•	•	•	1	1
138	S15287	4 PRONG FORKS	•	•	2	•	•	2	2	2	•	•	•	•	2	2
139	20006-000	ROTISSERIE BRACKET	•	•	1	•	•	1	1	1	•	•	•	•	1	1
141	Y-11559	BOLT 1/4-20 X 1	2	2	2	2	2	2	2	2	2	2	2	2	2	2
142	S21125	SCREW #8 X 1/2	2	2	2	2	2	2	2	2	2	2	2	2	2	2
145	S21235	HINGE PIN	2	2	2	2	2	2	2	2	2	2	2	2	2	2
146	S21233	HITCH PIN CLIP	2	2	2	2	2	2	2	2	2	2	2	2	2	2
147	Y-11231	LID BUMPER	4	4	4	4	4	4	4	4	4	4	4	4	4	4
157	Y-12835	SCREW #6-32 X 1/4	•	•	•	2	2	2	4	4	•	•	2	2	4	4

PARTS LIST

[illegible]

